

BEFORE
THE PUBLIC SERVICE COMMISSION OF
SOUTH CAROLINA

DOCKET NO. 2015-_____ -G

In the Matter of)	
)	
Application of Piedmont Natural Gas)	PETITION
Company, Inc. for Approval of Modified)	
Meter Sampling Program)	
)	

Piedmont Natural Gas Company, Inc. (“Piedmont” or the “Company”), through counsel and pursuant to Rules 103-825 and 103-475 of the Rules and Regulations of the Public Service Commission of South Carolina (“Commission”), respectfully requests authorization from the Commission to modify its statistical meter sampling protocols. In support of its proposed modifications Piedmont respectfully shows to the Commission the following:

1. It is respectfully requested that any notices or other communications with respect to this Petition be sent to:

Jane Lewis-Raymond
Senior Vice President and Chief Legal, Compliance and External Relations Officer
Piedmont Natural Gas Company, Inc.
4720 Piedmont Row Drive
Charlotte, NC 28210
Telephone: 704-731-4261
jane.lewis-raymond@piedmontng.com

and

Scott M. Tyler
Moore & Van Allen PLLC
100 North Tryon Street, Suite 4700
Charlotte, NC 28202-4003
Telephone: 704-331-2463
scotttyler@mvalaw.com

2. Piedmont is incorporated under the laws of the state of North Carolina and is duly authorized by its Articles of Incorporation to engage in the business of transporting, distributing, and

selling natural gas. It is duly domesticated and is engaged in conducting the business above-mentioned in the states of South Carolina, North Carolina, and Tennessee. Piedmont is a public utility under the laws of this State, and its public utility operations in South Carolina are subject to the jurisdiction of this Commission.

3. Pursuant to Rule 103-475, among others, Piedmont engages in periodic sampling of its in-service meters to ensure that they are achieving overall accuracy. This statistical periodic sampling is in addition to testing that is required at various times by Commission Rules.

4. Piedmont's meter sampling program tests active meters that are serving customers which are at least 10 years old and which have not otherwise been tested in the last 10 years by removing the meter from the customer's premises and performing tests in Piedmont's centralized meter shop. Once the meter being tested has been removed, a replacement meter is installed in its place so that the customer's service is not interrupted. After the replacement meter is installed, a Piedmont employee must relight any gas appliances and perform safety checks to ensure that no leaks are present and that the customer's premise is safe.

5. If the customer is not present to allow the Piedmont employee inside to relight appliances and conduct safety checks, the replacement meter is left in the "off" position and a door card is left on the customer's door explaining that the customer must call Piedmont to schedule a time that the customer can be present to allow Piedmont to relight appliances, conduct safety checks and restore their gas service.

6. Currently, in approximately 42 percent of instances in which Piedmont visits the customer's premises to collect the sampled meter, the replacement meter is left in the "off" position due to the customer not being present. This is despite the fact that Piedmont undertakes significant efforts using multiple means to notify its customers when their meter will be replaced.

7. Piedmont's frequent inability to switch meters and fully restore service to customers in a single visit causes inconvenience for our customers and increases the Company's operating costs due to the necessity to make repeat visits to finish the process and restore customer service.

8. By this Petition, Piedmont is seeking approval of a minor modification to its meter sampling program in order to better serve its customers. Specifically, Piedmont seeks to modify the program to collect eligible sampled residential meters when a customer has requested an on-site service that requires the homeowner to be home. This will ensure that the customer is home when the sampled meter is collected, allowing Piedmont to relight appliances, ensure that they are safe and ensure that the customer's gas service is not interrupted.

9. This modification will improve efficiency of the meter sampling program by reducing the amount of instances that a Piedmont employee will make return trips in order to turn a customer's meter on following a replacement meter being installed. This increased efficiency will save the customer and the Company time and money. It will also minimize customer inconvenience associated with meter sampling.

10. This modification to the meter sampling program's residential meter collection procedures will not reduce or compromise the quality or integrity of the program in any way. Exhibit A shows the Company's meter sampling proposal as approved by the Commission in Docket No. 2003-24-G, with redline changes for the modifications proposed herein.

11. Piedmont has conferred with the South Carolina Office of Regulatory Staff regarding its proposed modification to its meter sampling program procedures and it is Piedmont's understanding that ORS has no objection to its proposals.

WHEREFORE, Piedmont Natural Gas Company, Inc. respectfully requests that the Commission grant authorization for Piedmont to implement the modification to its meter sampling program protocols described above.

Respectfully submitted, this the 27th day of July, 2015.

Piedmont Natural Gas Company, Inc.

/s/ Scott M. Tyler
Scott M. Tyler

OF COUNSEL:

Moore & Van Allen PLLC
100 North Tryon Street, Suite 4700
Charlotte, NC 28202-4003
Telephone: 704-331-2463
scotttyler@mvalaw.com

STATE OF NORTH CAROLINA
COUNTY OF MECKLENBURG

VERIFICATION

Pia Powers, being duly sworn, deposes and says that she is Director -
Regulatory Affairs of Piedmont Natural Gas Company, Inc., that as such, she has read
the foregoing documents and knows the contents thereof; that the same are true of her
own knowledge except as to those matters stated on information and belief and as to
those she believes them to be true.

Pia Powers
Pia Powers

Mecklenburg County, North Carolina
Signed and sworn to before me this day by Pia Powers

Date: 7/27/2015 Jacqueline M. Berry
Jacqueline M. Berry, Notary Public

(Official Seal) My commission expires: 11/29/2016




EXHIBIT A

Statistical Meter Sampling For Piedmont Natural Gas

Currently, under authorization of the Public Service Commission of South Carolina (PSC), Piedmont Natural Gas utilizes a statistical sampling plan to evaluate and determine the accuracy of residential and commercial natural gas meters. Piedmont's plan is based on the Sampling Procedures and Tables for Inspection by Variables for Percent Non-Conforming, ANSI/ASQC Z1.9-1993. Piedmont has utilized this plan in South Carolina since 2003.

Piedmont is currently proposing to modify the sampling plan to collect eligible sampled residential meters when a customer has requested an on-site service that requires the homeowner to be home. This will ensure that the customer is home when the sampled meter is collected, allowing Piedmont to relight appliances, ensure that they are safe and ensure that the customer's gas service is not interrupted.

The proposed modification will not in any way change from the existing sampling plan the determination of the sample size. Meters will continue to be divided among the same groups as based on the manufacturer, the volume that can be passed (size), and install date. The AQL (Acceptable Quality Level) for the newly proposed plan will remain at 6.5, which is the same as the existing plan. The overall accuracy for the new plan is identical to the existing one in that 93.5% or more of the meters remaining in service will be within \pm 3% proof.

In the following pages, a sample calculation is provided to outline the actual procedure that is utilized under the current approved plan, and indicates the area of proposed plan modification with the context of a sample calculation.

Meter Inspection Groups

The meter inspection groups will be determined the exact same way as currently determined. Piedmont will continue to separate and record the statistical meter data that is accumulated by the following criteria:

1. The Last Record of Year Tested
2. Manufacturer
3. Case or Body Type (Aluminum Case)
4. Diaphragm Material (Synthetic)

Each inspection group will be composed of meters that have essentially the same operating characteristics. Each inspection group will also consist of meters that have been in service for equivalent amounts of time. This combination group will then be tested accordingly, by the prescribed criteria.

The scheduled testing for our meters can be broken down into two time frames among eight actual inspection groups. The following chart depicts both:

Group#	Meter Type	Yearly Testing Span
I	American 5B 225 American AL-175	10th year since last test and all subsequent years
II	Rockwell250, 175, 200 250 2 #set- 250	10th year since last test and all subsequent years
III	American AL-425	5th year since last test and all subsequent years
IV	Rockwell 415	5th year since last test and all subsequent years
V	American AL-800 With or without 1OOLb Case	5th year since last test and all subsequent years
VI	Rockwell 750	5th year since last test and all subsequent years
VII	Dresser 1.5 M Rotaries with Counters and ID versions	5th year since last test and all subsequent years
VIII	RM 1500 and RM 2000	5th year since last test and all subsequent years

The proposed sample test that will be performed will utilize the same Acceptable Quality Limit (AQL) as the current program. The current AQL is 6.5 and has proven a viable level of certainty for the tests performed. Cross-referring the chart from Table B-3 (Appendix 4) with this AQL and the sample size will produce a Maximum Allowable Percent Non-Conforming value that will be used to judge the actual statistical data computations of the sample group.

Determining Sample Size

In determining the sample size for each inspection group, the process will be the same as the current process, except a different chart will be used.

1. Once the inspection group has been determined by the last recorded year of sample test, and the amount of meters in the inspection group has been finalized, the new meter sample size shall be determined by referencing Appendix 1, "BATCH AND SAMPLE SIZE RATIO WITH CORRESPONDING PERCENT NON CONFORMING", or Appendix 2, "Sample Size Code Letters", directly from the proposed plan itself.
2. Using the total meters in the inspection group and the General Inspection Level II, the sample size code letter shall be determined.
3. Referencing the ANSI/ASQC Z1.9-1993, Table B-3 (Appendix 4), "Master Table for Normal and Tightened Inspection for Plans Based on Variability Unknown", utilizing the code letter determined above, and referencing an AQL of 6.5 for normal inspection, an inspection group sample size and a maximum allowable percent non-conforming shall be determined.

Example of Inspection Group

Total installed meters in group	=2309
Sample Size Code Letter	=K
Sample Size	=50
Maximum Allowable Percent Non-Conforming	= 11.23

For residential meter group nos. 1 & 2, the following process will identify the random selection of meters that are to comprise the actual sample size:

Each night automated reports will run and flag customer-initiated service orders scheduled for the next 1-2 business days that meet both the meter group/type and year of meter installation criteria of our sampling program. Sample test orders will then be generated and chained with the customer initiated service request, to be worked at the same time by each respective district/resource center. Customer-initiated orders that require the customer to be home will be targeted to sample tests orders. This will require no additional disruption of service to the customer.

In the event that the sample size cannot be met to its entirety by chaining to customer-initiated service orders, random selection for the remaining samples will follow the process outlined below.

For all other meter groups, the random selection of the meters that are to comprise the actual sample size will be chosen by the following formula:

~~The random selection of the meters that are to comprise the actual sample size will be chosen by the following formula:~~

Total Meters in Inspection Group / Sample Size = Computer Selection Number.

Utilizing the above Inspection Group, the following will give exact numbers:

2309 / Sample Size 50 = 46

In this example, every 46th meter will be selected until the 50 total sample size meters are compiled. Once the entire sample size has been compiled (minus meter groups 1 & 2 which will follow the process outlined above), the newly created list will be forwarded to each appropriate District Operations Facility, where the actual meter retrieval will transpire.

Once the meters have been taken out of service and shipped to the appropriate district, the actual proofing of the meter will occur. Each individual meter will be tested and each proof will be recorded in Piedmont's mainframe system. Once each proof has been compiled for the sample size, the actual statistical computations will be completed. Upon completion of the computations in the mainframe, a computerized list will be generated depicting the passed and failed meters as well as the group as a whole. The appropriate actions will be taken to ensure that Piedmont follows the statutes that govern the utilities industry for South Carolina.

Damaged and Un-Repaired Meters

Upon determining that a meter is or has been damaged and has not been repaired, the meter will be removed from the sample group and replaced with another random selection from the same Inspection Group. In the case of a damaged meter belonging to meter groups 1 or 2, the next available customer-requested order that meets the sample program criteria will have a meter sample order chained to it, and will be taken out of service in the field. In the example above which outlines the process for all other meter groups, the next 46th meter would be selected from the original 2309.

Statistically Invalid Meters

The program has a process to accommodate the meters that vary a certain amount from the sample mean. This process allows for a meter that is \pm 4 standard deviations away from the sample mean to be removed from the calculations. These removed meters will be referred to as "SIM" meters (Statistically Invalid Meters). A correction factor must be added back into the total percent non-conforming to account for these removed meters. This correction factor will be equal to the number of "SIM" meters divided by the sample size.

APPENDIX 1

**BATCH AND SAMPLE SIZE RATIO WITH
CORRESPONDING PERCENT NON -CONFORMING**

Batch Size	Sample Size Code	Sample Size	In Service Max Allowable Percent Non Conforming
2 to 15	B	3	26.94
16 to 25	C	4	22.84
26 to 50	D	5	20.19
51 to 90	E	7	17.34
91 to 150	F	10	15.17
151 to 280	G	15	13.74
281 to 400	H	20	13.01
401 to 500	I	25	12.60
501 to 1200	J	35	11.89
1201 to 3200	K	50	11.23
3201 to 10000	L	75	10.58
10001 to 35000	M	100	10.29
35001 to 150000	N	150	9.86
150001 and Over	P	200	9.80

APPENDIX 2

TABLE A-1
AQL Conversion Table

For specified AQL values falling within these ranges	Use this AQL value
- to 0.109	0.10
0.110 to 0.164	0.15
0.165 to 0.279	0.25
0.280 to 0.439	0.40
0.440 to 0.669	0.65
0.700 to 1.09	1.0
1.10 to 1.64	1.5
1.65 to 2.79	2.5
2.80 to 4.39	4.0
4.40 to 6.99	6.5
7.00 to 10.9	10.0

TABLE A-2²
Sample Size Code Letters¹

Lot Size	Inspection Levels		
	Special S3 S4	General I n m	
2 to 8	B B	BBC	
9 to 15	B B	BBD	
16 to 25	B B	BCE	
26 to 50	B B	CDF	
51 to 90	B B	DEG	
91 to 150	B C	E FH	
151 to 280	B D	F G I	
281 to 400	C E	G H J	
401 to 500	C E	G I J	
501 to 1,200	D F	H J K	
1,201 to 3,200	E G	I K L	
3,201 to 10,000	F H	JLM	
10,001 to 35,000	G I	KMN	
35,001 to 150,000	H J	L N P	
150,001 to 500,000	H K	MPP	
500,001 and over	H K	NPP	

¹sample size code letters given in body of table are applicable when the indicated inspection levels are to be used.

²The theory governing inspection by variables depends on the properties of the normal distribution and, therefore, this method of inspection is only applicable when there is reason to believe that the frequency distribution is normal.

APPENDIX 3

Table B-3

Standard Deviation Method

Master Table for Normal and Tightened Inspection for Plans Based on Variability Unknown
(Double Specification Limit and Form 2-Single Specification Limit)

Sample size code letter	Sample size	Acceptable Quality Levels (normal inspection)											
		T	.10	.15	.25	.40	.65	1.00	1.50	2.50	4.00	6.50	10.00
		M	M	M	M	M	M	M	M	M	M	M	M
B	3							t	t	7.59	18.86	26.94	33.69
C	4							1.49	5.46	10.88	16.41	22.84	29.43
D	5					0.041	1.34	3.33	5.82	9.80	14.37	20.19	26.55
E	7		0.005	0.087	0.421	1.05	2.13	3.54	5.34	8.40	12.19	17.34	23.30
F	10	0.077	0.179	0.349	0.714	1.27	2.14	3.27	4.72	7.26	10.53	15.17	20.73
G	15	0.186	0.311	0.491	0.839	1.33	2.09	3.06	4.32	6.55	9.48	13.74	18.97
H	20	0.228	0.356	0.531	0.864	1.33	2.03	2.93	4.10	6.18	8.95	13.01	18.07
I	25	0.250	0.378	0.551	0.874	1.32	2.00	2.86	3.97	5.98	8.65	12.60	17.55
J	35	0.253	0.373	0.534	0.833	1.24	1.87	2.66	3.70	5.58	8.11	11.89	16.67
K	50	0.243	0.355	0.503	0.778	1.16	1.73	2.47	3.44	5.21	7.61	11.23	15.87
L	75	0.225	0.326	0.461	0.711	1.06	1.59	2.27	3.17	4.83	7.10	10.58	15.07
M	100	0.218	0.315	0.444	0.684	1.02	1.52	2.18	3.06	4.67	6.88	10.29	14.71
N	150	0.202	0.292	0.412	0.636	0.946	1.42	2.05	2.88	4.42	6.56	9.86	14.18
P	200	0.204	0.294	0.414	0.637	0.945	1.42	2.04	2.86	4.39	6.52	9.80	14.11
		.10	.15	.25	.40	.65	1.00	1.50	2.50	4.00	6.50	10.00	
		Acceptable Quality Levels (tightened inspection)											

All AQL values are in percent nonconforming. T denotes plan used exclusively on tightened inspection and provides symbol for identification of appropriate OC curve.

| Use first sampling plan below arrow; that is, both sample size as well as M value. When sample size equals or t exceeds lot size, every item in the lot must be inspected.

APPENDIX 4

Table B-5

Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method¹

Qu QL	Sample Size														
	3	4	5	7	10	15	20	25	30	35	50	75	100	150	200
.0	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00	50.00
.1	47.24	46.67	46.44	46.26	46.16	46.10	46.08	46.06	46.05	46.05	46.04	46.03	46.03	46.02	46.02
.2	44.46	43.33	42.90	42.54	42.35	42.24	42.19	42.16	42.15	42.13	42.11	42.10	42.09	42.09	42.08
.3	41.63	40.00	39.37	38.87	38.60	38.44	38.37	38.33	38.31	38.29	38.27	38.25	38.24	38.23	38.22
.31	41.35	39.67	39.02	38.50	38.23	38.06	37.99	37.95	37.93	37.91	37.89	37.87	37.86	37.85	37.84
.32	41.06	39.33	38.67	38.14	37.86	37.69	37.62	37.58	37.55	37.54	37.51	37.49	37.48	37.47	37.46
.33	40.77	39.00	38.32	37.78	37.49	37.31	37.24	37.20	37.18	37.16	37.13	37.11	37.10	37.09	37.08
.34	40.49	38.67	37.97	37.42	37.12	36.94	36.87	36.83	36.80	36.78	36.75	36.73	36.72	36.71	36.71
.35	40.20	38.33	37.62	37.06	36.75	36.57	36.49	36.45	36.43	36.41	36.38	36.36	36.35	36.34	36.33
.36	39.91	38.00	37.28	36.69	36.38	36.20	36.12	36.08	36.05	36.04	36.01	35.98	35.97	35.96	35.96
.37	39.62	37.67	36.93	36.33	36.02	35.83	35.75	35.71	35.68	35.66	35.63	35.61	35.60	35.59	35.58
.38	39.33	37.33	36.58	35.98	35.65	35.46	35.38	35.34	35.31	35.29	35.26	35.24	35.23	35.22	35.21
.39	39.03	37.00	36.23	35.62	35.29	35.10	35.02	34.97	34.94	34.93	34.89	34.87	34.86	34.85	34.84
.40	38.74	36.67	35.88	35.26	34.93	34.73	34.65	34.60	34.58	34.56	34.53	34.50	34.49	34.48	34.47
.41	38.45	36.33	35.54	34.90	34.57	34.37	34.28	34.24	34.21	34.19	34.16	34.13	34.12	34.11	34.11
.42	38.15	36.00	35.19	34.55	34.21	34.00	33.92	33.87	33.85	33.83	33.79	33.77	33.76	33.75	33.74
.43	37.85	35.67	34.85	34.19	33.85	33.64	33.56	33.51	33.48	33.46	33.43	33.40	33.39	33.38	33.38
.44	37.56	35.33	34.50	33.84	33.49	33.28	33.20	33.15	33.12	33.10	33.07	33.04	33.03	33.02	33.01
.45	37.26	35.00	34.16	33.49	33.13	32.92	32.84	32.79	32.76	32.74	32.71	32.68	32.67	32.66	32.65
.46	36.96	34.67	33.81	33.13	32.78	32.57	32.48	32.43	32.40	32.38	32.35	32.32	32.31	32.30	32.29
.47	36.66	34.33	33.47	32.78	32.42	32.21	32.12	32.07	32.04	32.02	31.99	31.96	31.95	31.94	31.93
.48	36.35	34.00	33.12	32.43	32.07	31.85	31.77	31.72	31.69	31.67	31.63	31.61	31.60	31.58	31.58
.49	36.05	33.67	32.78	32.08	31.72	31.50	31.41	31.36	31.33	31.31	31.28	31.25	31.24	31.23	31.22
.50	35.75	33.33	32.44	31.74	31.37	31.15	31.06	31.01	30.98	30.96	30.93	30.90	30.89	30.88	30.87
.51	35.44	33.00	32.10	31.39	31.02	30.80	30.71	30.66	30.63	30.61	30.57	30.55	30.54	30.53	30.52
.52	35.13	32.67	31.76	31.04	30.67	30.45	30.36	30.31	30.28	30.26	30.23	30.20	30.19	30.18	30.17
.53	34.82	32.33	31.42	30.70	30.32	30.10	30.01	29.96	29.93	29.91	29.88	29.85	29.84	29.83	29.82
.54	34.51	32.00	31.08	30.36	29.98	29.76	29.67	29.62	29.59	29.57	29.53	29.51	29.49	29.48	29.48
.55	34.20	31.67	30.74	30.01	29.64	29.41	29.32	29.27	29.24	29.22	29.19	29.16	29.15	29.14	29.13
.56	33.88	31.33	30.40	29.67	29.29	29.07	28.98	28.93	28.90	28.88	28.85	28.82	28.81	28.80	28.79
.51	33.57	31.00	30.06	29.33	28.95	28.73	28.64	28.59	28.56	28.54	28.51	28.48	28.47	28.46	28.45
.58	33.25	30.67	29.73	28.99	28.61	28.39	28.30	28.25	28.22	28.20	28.17	28.14	28.13	28.12	28.11
.59	32.93-	30.33	29.39	28.66	28.28	28.05	27.96	27.92	27.89	27.87	27.83	27.81	27.79	27.78	27.78
.60	32.61	30.00	29.05	28.32	27.94	27.72	27.63	27.5S	27.55	27.53	27.50	27.47	27.46	27.45	27.44
.61	32.28	29.67	28.72	27.98	27.60	27.39	27.30	27.25	27.22	27.20	27.16	27.14	27.13	27.11	27.11
.62	31.96	29.33	28.39	27.65	27.27	27.05	26.96	26.92	26.89	26.87	26.83	26.81	26.80	26.78	26.78
.63	31.63	29.00	28.05	27.32	26.94	26.72	26.63	26.59	26.56	26.54	26.50	26.48	26.47	26.46	26.45
.64	31.30	28.67	27.72	26.99	26.61	26.39	26.31	26.26	26.23	26.21	26.18	26.15	26.14	26.13	26.12
.65	30.97	28.33	27.39	26.66	26.28	26.07	25.98	25.93	25.90	25.88	25.85	25.83	25.82	25.81	25.80
.66	30.63	28.00	27.06	26.33	25.96	25.74	25.66	25.61	25.58	25.56	25.53	25.51	25.49	25.48	25.48
.67	30.30	27.67	26.73	26.00	25.63	25.42	25.33	25.29	25.26	25.24	25.21	25.19	25.17	25.16	25.16
.68	29.96	27.33	26.40	25.68	25.31	25.10	25.01	24.97	24.94	24.92	24.89	24.87	24.86	24.85	24.84
.69	29.61	27.00	26.07	25.35	24.99	24.78	24.70	24.65	24.62	24.60	24.57	24.55	24.54	24.53	24.52

¹Values tabulated are read in percent.

*Table B-5-Continued*Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method¹

Qu or QL	Sample Size														
	3	4	5	7	10	15	20	25	30	35	50	75	100	150	200
.70	29.27	26.67	25.74	25.03	24.67	24.46	24.38	24.33	24.31	24.29	24.26	24.24	24.23	24.22	24.21
.71	28.92	26.33	25.41	24.71	24.35	24.15	24.06	24.02	23.99	23.98	23.95	23.92	23.91	23.90	23.90
.72	28.57	26.00	25.09	24.39	24.03	23.83	23.75	23.71	23.68	23.67	23.64	23.61	23.60	23.59	23.59
.73	28.22	25.67	24.76	24.07	23.72	23.52	23.44	23.40	23.37	23.36	23.33	23.31	23.30	23.29	23.28
.74	27.86	25.33	24.44	23.75	23.41	23.21	23.13	23.09	23.07	23.05	23.02	23.00	22.99	22.98	22.98
.75	27.50	25.00	24.11	23.44	23.10	22.90	22.83	22.79	22.76	22.75	22.72	22.70	22.69	22.68	22.68
.76	27.13	24.67	23.79	23.12	22.79	22.60	22.52	22.48	22.46	22.44	22.42	22.40	22.39	22.38	22.38
.77	26.76	24.33	23.47	22.81	22.48	22.30	22.22	22.18	22.16	22.14	22.12	22.10	22.09	22.08	22.08
.78	26.39	24.00	23.15	22.50	22.18	21.99	21.92	21.89	21.86	21.85	21.82	21.80	21.78	21.79	21.78
.79	26.02	23.67	22.83	22.19	21.87	21.70	21.63	21.59	21.57	21.55	21.53	21.51	21.50	21.49	21.49
.80	25.64	23.33	22.51	21.88	21.57	21.40	21.33	21.29	21.27	21.26	21.23	21.22	21.21	21.20	21.20
.81	25.25	23.00	22.19	21.58	21.27	21.10	21.04	21.00	20.98	20.97	20.94	20.93	20.92	20.91	20.91
.82	24.86	22.67	21.87	21.27	20.98	20.81	20.75	20.71	20.69	20.68	20.65	20.64	2Q.63	20.62	20.62
.83	24.47	22.33	21.56	20.97	20.68	20.52	20.46	20.42	20.40	20.39	20.37	20.35	20.35	20.34	20.34
.84	24.07	22.00	21.24	20.67	20.39	20.23	20.17	20.14	20.12	20.11	20.09	20.07	20.06	20.06	20.05
.85	23.67	21.67	20.93	20.37	20.10	19.94	19.89	19.86	19.84	19.82	19.80	19.79	19.78	19.78	19.77
.86	23.26	21.33	20.62	20.07	19.81	19.66	19.60	19.57	19.56	19.54	19.53	19.51	19.51	19.50	19.50
.87	22.84	21.00	20.31	19.78	19.52	19.38	19.32	19.30	19.28	19.27	19.25	19.24	19.23	19.23	19.22
.88	22.42	20.67	20.00	19.48	19.23	19.10	19.05	19.02	19.00	18.99	18.98	18.96	18.96	18.95	18.95
.89	21.99	20.33	19.69	19.19	18.95	18.82	18.77	18.74	18.73	18.72	18.70	18.69	18.69	18.68	18.68
.90	21.55	20.00	19.38	18.90	18.67	18.54	18.50	18.47	18.46	18.45	18.43	18.42	18.42	18.41	18.41
.91	21.11	19.67	19.07	18.61	18.39	18.27	18.23	18.20	18.19	18.18	18.17	18.16	18.15	18.15	18.15
.92	20.66	19.33	18.77	18.33	18.11	18.00	17.96	17.94	17.92	17.92	17.90	17.89	17.89	17.89	17.88
.93	20.19	19.00	18.46	18.04	17.84	17.73	17.69	17.67	17.66	17.65	17.64	17.63	17.63	17.62	17.62
.94	19.73	18.67	18.16	17.76	17.56	17.46	17.43	17.41	17.40	17.39	17.38	17.37	17.37	17.37	17.36
.95	19.25	18.33	17.86	17.48	17.29	17.20	17.17	17.16	17.14	17.13	17.12	17.12	17.11	17.11	17.11
.96	18.75	18.00	17.55	17.20	17.03	16.94	16.90	16.89	16.88	16.88	16.87	16.86	16.86	16.86	16.86
.97	18.25	17.67	17.25	16.92	16.76	16.68	16.65	16.63	16.63	16.62	16.61	16.61	16.61	16.61	16.60
.98	17.74	17.33	16.96	16.65	16.49	16.42	16.39	16.38	16.37	16.37	16.36	16.36	16.36	16.36	16.36
.99	17.21	17.00	16.66	16.37	16.23	16.16	16.14	16.13	16.12	16.12	16.11	16.11	16.11	16.11	16.11
1.00	16.67	16.67	16.36	16.10	15.97	15.91	15.89	15.88	15.88	15.87	15.87	15.87	15.87	15.87	15.87
1.01	16.11	16.33	16.07	15.83	15.72	15.66	15.64	15.63	15.63	15.63	15.63	15.62	15.62	15.62	15.62
1.02	15.53	16.00	15.78	15.56	15.46	15.41	15.40	15.39	15.39	15.38	15.38	15.38	15.38	15.39	15.39
1.03	14.93	15.67	15.48	15.30	15.21	15.17	15.15	15.15	15.15	15.15	15.15	15.15	15.15	15.15	15.15
1.04	14.31	15.33	15.19	15.03	14.96	14.92	14.91	14.91	14.91	14.91	14.91	14.91	14.91	14.91	14.91
1.05	13.66	15.00	14.91	14.77	14.71	14.68	14.67	14.67	14.67	14.67	14.68	14.68	14.68	14.68	14.68
1.06	12.98	14.67	14.62	14.51	14.46	14.44	14.44	14.44	14.44	14.44	14.45	14.45	14.45	14.45	14.45
1.07	12.27	14.33	14.33	14.26	14.22	14.20	14.20	14.21	14.21	14.21	14.22	14.22	14.22	14.23	14.22
1.08	11.51	14.00	14.05	14.00	13.97	13.97	13.97	13.98	13.98	13.98	13.99	13.99	14.00	14.00	14.00
1.09	10.71	13.67	13.76	13.75	13.73	13.74	13.74	13.75	13.75	13.76	13.77	13.77	13.78	13.78	13.78

¹Values tabulated are read in percent.

*Table B-5-Continued*Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method¹

Out or QL	Sample Size														
	3	4	5	7	10	15	20	25	30	35	50	75	100	150	200
1.10	9.84	13.33	13.48	13.49	13.50	13.51	13.52	13.52	13.53	13.54	13.54	13.55	13.55	13.56	13.56
1.11	8.89	13.00	13.20	13.25	13.26	13.28	13.29	13.30	13.31	13.31	13.32	13.33	13.34	13.34	13.34
1.12	7.82	12.67	12.93	13.00	13.03	13.05	13.07	13.08	13.09	13.10	13.11	13.12	13.12	13.13	13.13
1.13	6.60	12.33	12.65	12.75	12.80	12.83	12.85	12.86	12.87	12.88	12.89	12.90	12.91	12.91	12.92
1.14	5.08	12.00	12.37	12.51	12.57	12.61	12.63	12.65	12.66	12.67	12.68	12.69	12.70	12.70	12.71
1.15	2.87	11.67	12.10	12.27	12.34	12.39	12.42	12.44	12.45	12.46	12.47	12.48	12.49	12.49	12.50
1.16	0.00	11.33	11.83	12.03	12.12	12.18	12.21	12.22	12.24	12.25	12.26	12.28	12.28	12.29	12.29
1.17	0.00	11.00	11.56	11.79	11.90	11.96	12.00	12.02	12.03	12.04	12.06	12.07	12.08	12.09	12.09
1.18	0.00	10.67	11.29	11.56	11.68	11.75	11.79	11.81	11.82	11.84	11.85	11.87	11.88	11.88	11.89
1.19	0.00	10.33	11.02	11.33	11.46	11.54	11.58	11.61	11.62	11.63	11.65	11.67	11.68	11.69	11.69
1.20	0.00	10.00	10.76	11.10	11.24	11.34	11.38	11.41	11.42	11.43	11.46	11.47	11.48	11.49	11.49
1.21	0.00	9.67	10.50	10.87	11.03	11.13	11.18	11.21	11.22	11.24	11.26	11.28	11.29	11.30	11.30
1.22	0.00	9.33	10.23	10.65	10.82	10.93	10.98	11.01	11.03	11.04	11.07	11.09	11.09	11.10	11.11
1.23	0.00	9.00	9.97	10.42	10.61	10.73	10.78	10.81	10.84	10.85	10.88	10.90	10.91	10.92	10.92
1.24	0.00	8.67	9.72	10.20	10.41	10.53	10.59	10.62	10.64	10.66	10.69	10.71	10.72	10.73	10.73
1.25	0.00	8.33	9.46	9.98	10.21	10.34	10.40	10.43	10.46	10.47	10.50	10.52	10.53	10.54	10.55
1.26	0.00	8.00	9.21	9.77	10.00	10.15	10.21	10.25	10.27	10.29	10.32	10.34	10.35	10.36	10.37
1.27	0.00	7.67	8.96	9.55	9.81	9.96	10.02	10.06	10.09	10.10	10.13	10.16	10.17	10.18	10.19
1.28	0.00	7.33	8.71	9.34	9.61	9.77	9.84	9.88	9.90	9.92	9.95	9.98	9.99	10.00	10.01
1.29	0.00	7.00	8.46	9.13	9.42	9.58	9.66	9.70	9.72	9.74	9.78	9.80	9.82	9.83	9.83
1.30	0.00	6.67	8.21	8.93	9.22	9.40	9.48	9.52	9.55	9.57	9.60	9.63	9.64	9.65	9.66
1.31	0.00	6.33	7.97	8.72	9.03	9.22	9.30	9.34	9.37	9.39	9.43	9.46	9.47	9.48	9.49
1.32	0.00	6.00	7.73	8.52	8.85	9.04	9.12	9.17	9.20	9.22	9.26	9.29	9.30	9.31	9.32
1.33	0.00	5.67	7.49	8.32	8.66	8.86	8.95	9.00	9.03	9.05	9.09	9.12	9.13	9.15	9.15
1.34	0.00	5.33	7.25	8.12	8.48	8.69	8.78	8.83	8.86	8.88	8.92	8.95	8.97	8.98	8.99
1.35	0.00	5.00	7.02	7.92	8.30	8.52	8.61	8.66	8.69	8.72	8.76	8.79	8.81	8.82	8.83
1.36	0.00	4.67	6.79	7.73	8.12	8.35	8.44	8.50	8.53	8.55	8.60	8.63	8.65	8.66	8.67
1.37	0.00	4.33	6.56	7.54	7.95	8.18	8.28	8.33	8.37	8.39	8.44	8.47	8.49	8.50	8.51
1.38	0.00	4.00	6.33	7.35	7.77	8.01	8.12	8.17	8.21	8.24	8.28	8.31	8.33	8.35	8.36
1.39	0.00	3.67	6.10	7.17	7.60	7.85	7.96	8.01	8.05	8.08	8.12	8.16	8.18	8.19	8.20
1.40	0.00	3.33	5.88	6.98	7.44	7.69	7.80	7.86	7.90	7.92	7.97	8.01	8.02	8.04	8.05
1.41	0.00	3.00	5.66	6.80	7.27	7.53	7.64	7.70	7.74	7.77	7.82	7.86	7.87	7.89	7.90
1.42	0.00	2.67	5.44	6.62	7.10	7.37	7.49	7.55	7.59	7.62	7.67	7.71	7.73	7.74	7.75
1.43	0.00	2.33	5.23	6.45	6.94	7.22	7.34	7.40	7.44	7.47	7.52	7.56	7.58	7.60	7.61
1.44	0.00	2.00	5.02	6.27	6.78	7.07	7.19	7.26	7.30	7.33	7.38	7.42	7.44	7.46	7.47
1.45	0.00	1.67	4.81	6.10	6.63	6.92	7.04	7.11	7.15	7.18	7.24	7.28	7.30	7.32	7.32
1.46	0.00	1.33	4.60	5.93	6.47	6.77	6.90	6.97	7.01	7.04	7.10	7.14	7.16	7.18	7.19
1.47	0.00	1.00	4.39	5.77	6.32	6.63	6.75	6.83	6.87	6.90	6.96	7.00	7.02	7.04	7.05
1.48	0.00	.67	4.19	5.60	6.17	6.48	6.61	6.69	6.73	6.77	6.82	6.86	6.88	6.90	6.91
1.49	0.00	.33	3.99	5.44	6.02	6.34	6.48	6.55	6.60	6.63	6.69	6.73	6.75	6.77	6.78

'Values tabulated are read in percent.

Table B-5--Continued

Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method¹

Qu or QL	Sample Size														
	3	4	5	7	10	15	20	25	30	35	50	75	100	150	200
1.50	0.00	0.00	3.80	5.28	5.87	6.20	6.34	6.41	6.46	6.50	6.55	6.60	6.62	6.64	6.65
1.51	0.00	0.00	3.61	5.13	5.73	6.06	6.20	6.28	6.33	6.36	6.42	6.47	6.49	6.51	6.52
1.52	0.00	0.00	3.42	4.97	5.59	5.93	6.07	6.15	6.20	6.23	6.29	6.34	6.36	6.38	6.39
1.53	0.00	0.00	3.23	4.82	5.45	5.80	5.94	6.02	6.07	6.11	6.17	6.21	6.24	6.26	6.27
1.54	0.00	0.00	3.05	4.67	5.31	5.67	5.81	5.89	5.95	5.98	6.04	6.09	6.11	6.13	6.15
1.55	0.00	0.00	2.87	4.52	5.18	5.54	5.69	5.77	5.82	5.86	5.92	5.97	5.99	6.01	6.02
1.56	0.00	0.00	2.69	4.38	5.05	5.41	5.56	5.65	5.70	5.74	5.80	5.85	5.87	5.89	5.90
1.57	0.00	0.00	2.52	4.24	4.92	5.29	5.44	5.53	5.58	5.62	5.68	5.73	5.75	5.78	5.79
1.58	0.00	0.00	2.35	4.10	4.79	5.16	5.32	5.41	5.46	5.50	5.56	5.61	5.64	5.66	5.67
1.59	0.00	0.00	2.19	3.96	4.66	5.04	5.20	5.29	5.34	5.38	5.45	5.50	5.52	5.55	5.56
1.60	0.00	0.00	2.03	3.83	4.54	4.92	5.08	5.17	5.23	5.27	5.33	5.38	5.41	5.43	5.44
1.61	0.00	0.00	1.87	3.69	4.41	4.81	4.97	5.06	5.12	5.16	5.22	5.27	5.30	5.32	5.33
1.62	0.00	0.00	1.72	3.57	4.30	4.69	4.86	4.95	5.01	5.04	5.11	5.16	5.19	5.21	5.23
1.63	0.00	0.00	1.57	3.44	4.18	4.58	4.75	4.84	4.90	4.94	5.01	5.06	5.08	5.11	5.12
1.64	0.00	0.00	1.42	3.31	4.06	4.47	4.64	4.73	4.79	4.83	4.90	4.95	4.98	5.00	5.01
1.65	0.00	0.00	1.28	3.19	3.95	4.36	4.53	4.62	4.68	4.72	4.79	4.85	4.87	4.90	4.91
1.66	0.00	0.00	LIS	3.07	3.84	4.25	4.43	4.52	4.58	4.62	4.69	4.74	4.77	4.80	4.81
1.67	0.00	0.00	1.02	2.95	3.73	4.15	4.32	4.42	4.48	4.52	4.59	4.64	4.67	4.70	4.71
1.68	0.00	0.00	0.89	2.84	3.62	4.05	4.22	4.32	4.38	4.42	4.49	4.55	4.57	4.60	4.61
1.69	0.00	0.00	0.77	2.73	5.52	3.94	4.12	4.22	4.28	4.32	4.39	4.45	4.47	4.50	4.51
1.70	0.00	0.00	0.66	2.62	3.41	3.84	4.02	4.12	4.18	4.22	4.30	4.35	4.38	4.41	4.42
1.71	0.00	0.00	0.55	2.51	3.31	3.75	3.93	4.02	4.09	4.13	4.20	4.26	4.29	4.31	4.32
1.72	0.00	0.00	0.45	2.41	3.21	3.65	3.83	3.93	3.99	4.04	4.11	4.17	4.19	4.22	4.23
1.73	0.00	0.00	0.36	2.30	3.11	3.56	3.74	3.84	3.90	3.94	4.02	4.08	4.10	4.13	4.14
1.74	0.00	0.00	0.27	2.20	3.02	3.46	3.65	3.75	3.81	3.85	3.93	3.99	4.01	4.04	4.05
1.75	0.00	0.00	0.19	2.11	2.93	3.37	3.56	3.66	3.72	3.77	3.84	3.90	3.93	3.95	3.97
1.76	0.00	0.00	0.12	2.01	2.83	3.28	3.47	3.57	3.63	3.68	3.76	3.81	3.84	3.87	3.88
1.77	0.00	0.00	0.06	1.92	2.74	3.20	3.38	3.48	3.55	3.59	3.67	3.73	3.76	3.78	3.80
1.78	0.00	0.00	0.02	1.83	2.66	3.11	3.30	3.40	3.47	3.51	3.59	3.64	3.67	3.70	3.71
1.79	0.00	0.00	0.00	1.74	2.57	3.03	3.21	3.32	3.38	3.43	3.51	3.56	3.59	3.62	3.63
1.80	0.00	0.00	0.00	1.65	2.49	2.94	3.13	3.24	3.30	3.35	3.43	3.48	3.51	3.54	3.55
1.81	0.00	0.00	0.00	1.57	2.40	2.86	3.05	3.16	3.22	3.27	3.35	3.40	3.43	3.46	3.47
1.82	0.00	0.00	0.00	1.49	2.32	2.79	2.98	3.08	3.15	3.19	3.27	3.33	3.36	3.38	3.40
1.83	0.00	0.00	0.00	1.41	2.25	2.71	2.90	3.00	3.07	3.11	3.19	3.25	3.28	3.31	3.32
1.84	0.00	0.00	0.00	1.34	2.17	2.63	2.82	2.93	2.99	3.04	3.12	3.18	3.21	3.23	3.25
1.85	0.00	0.00	0.00	1.26	2.09	2.56	2.75	2.85	2.92	2.97	3.05	3.10	3.13	3.16	3.17
1.86	0.00	0.00	0.00	1.19	2.02	2.48	2.68	2.78	2.85	2.89	2.97	3.03	3.06	3.09	3.10
1.87	0.00	0.00	0.00	1.12	1.95	2.41	2.61	2.71	2.78	2.82	2.90	2.96	2.99	3.02	3.03
1.88	0.00	0.00	0.00	1.06	1.88	2.34	2.54	2.64	2.71	2.75	2.83	2.89	2.92	2.95	2.96
1.89	0.00	0.00	0.00	0.99	1.81	2.28	2.47	2.57	2.64	2.69	2.77	2.83	2.85	2.88	2.90

¹Values tabulated are read in percent.

Table B-5-Continued

Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method^a

Qu or QL	Sample Size														
	3	4	5	7	10	15	20	25	30	35	50	75	100	150	200
1.90	0.00	0.00	0.00	0.93	1.75	2.21	2.40	2.51	2.57	2.62	2.70	2.76	2.79	2.82	2.83
1.91	0.00	0.00	0.00	0.87	1.68	2.14	2.34	2.44	2.51	2.56	2.63	2.69	2.72	2.75	2.77
1.92	0.00	0.00	0.00	0.81	1.62	2.08	2.27	2.38	2.45	2.49	2.57	2.63	2.66	2.69	2.70
1.93	0.00	0.00	0.00	0.76	1.56	2.02	2.21	2.32	2.38	2.43	2.51	2.57	2.60	2.63	2.64
1.94	0.00	0.00	0.00	0.70	1.50	1.96	2.15	2.25	2.32	2.37	2.45	2.51	2.54	2.56	2.58
1.95	0.00	0.00	0.00	0.65	1.44	1.90	2.09	2.19	2.26	2.31	2.39	2.45	2.48	2.50	2.52
1.96	0.00	0.00	0.00	0.60	1.38	1.84	2.03	2.14	2.20	2.25	2.33	2.39	2.42	2.44	2.46
1.97	0.00	0.00	0.00	0.56	1.33	1.78	1.97	2.08	2.14	2.19	2.27	2.33	2.36	2.39	2.40
1.98	0.00	0.00	0.00	0.51	1.27	1.73	1.92	2.02	2.09	2.13	2.21	2.27	2.30	2.33	2.34
1.99	0.00	0.00	0.00	0.47	1.22	1.67	1.86	1.97	2.03	2.08	2.16	2.22	2.25	2.27	2.29
2.00	0.00	0.00	0.00	0.43	1.17	1.62	1.81	1.91	1.98	2.03	2.10	2.16	2.19	2.22	2.23
2.01	0.00	0.00	0.00	0.39	1.12	1.57	1.76	1.86	1.93	1.97	2.05	2.11	2.14	2.17	2.18
2.02	0.00	0.00	0.00	0.36	1.07	1.52	1.71	1.81	1.87	1.92	2.00	2.06	2.09	2.11	2.13
2.03	0.00	0.00	0.00	0.32	1.03	1.47	1.66	1.76	1.82	1.87	1.95	2.01	2.04	2.06	2.08
2.04	0.00	0.00	0.00	0.29	0.98	1.42	1.61	1.71	1.77	1.82	1.90	1.96	1.99	2.01	2.03
2.05	0.00	0.00	0.00	0.26	0.94	1.37	1.56	1.66	1.73	1.77	1.85	1.91	1.94	1.96	1.98
2.06	0.00	0.00	0.00	0.23	0.90	1.33	1.51	1.61	1.68	1.72	1.80	1.86	1.89	1.92	1.93
2.07	0.40	0.00	0.00	0.21	0.86	1.28	1.47	1.57	1.63	1.68	1.76	1.81	1.84	1.87	1.88
2.08	0.00	0.00	0.00	0.18	0.82	1.24	1.42	1.52	1.59	1.63	1.71	1.77	1.79	1.82	1.84
2.09	0.00	0.00	0.00	0.16	0.78	1.20	1.38	1.48	1.54	1.59	1.66	1.72	1.75	1.78	1.79
2.10	0.00	0.00	0.00	0.14	0.74	1.16	1.34	1.44	1.50	1.54	1.62	1.68	1.71	1.73	1.75
2.11	0.00	0.00	0.00	0.12	0.71	1.12	1.30	1.39	1.46	1.50	1.58	1.63	1.66	1.69	1.70
2.12	0.00	0.00	0.00	0.10	0.67	1.08	1.26	1.35	1.42	1.46	1.54	1.59	1.62	1.65	1.66
2.13	0.00	0.00	0.00	0.08	0.64	1.04	1.22	1.31	1.38	1.42	1.50	1.55	1.58	1.61	1.62
2.14	0.00	0.00	0.00	0.07	0.61	1.00	1.18	1.28	1.34	1.38	1.46	1.51	1.54	1.57	1.58
2.15	0.00	0.00	0.00	0.06	0.58	0.97	1.14	1.24	1.30	1.34	1.42	1.47	1.50	1.53"	1.54
2.16	0.00	0.00	0.00	0.05	0.55	0.93	1.10	1.20	1.26	1.30	1.38	1.43	1.46	1.49	1.50
2.17	0.00	0.00	0.00	0.04	0.52	0.90	1.07	1.16	1.22	1.27	1.34	1.40	1.42	1.45	1.46
2.18	0.00	0.00	0.00	0.03	0.49	0.87	1.03	1.13	1.19	1.23	1.30	1.36	1.39	1.41	1.42
2.19	0.00	0.00	0.00	0.02	0.46	0.83	1.00	1.09	1.15	1.20	1.27	1.32	1.35	1.38	1.39
2.20	0.000	0.000	0.000	0.015	0.437	0.803	0.968	1.061	1.120	1.061	1.233	1.287	1.314	1.340	1.352
2.21	0.000	0.000	0.000	0.010	0.413	0.772	0.936	1.028	1.087	1.128	1.199	1.253	1.279	1.305	1.318
2.22	0.000	0.000	0.000	0.006	0.389	0.734	0.905	0.996	1.054	1.095	1.166	1.219	1.245	1.271	1.284
2.23	0.000	0.000	0.000	0.003	0.366	0.715	0.874	0.965	1.023	1.063	1.134	1.186	1.212	1.238	1.250
2.24	0.000	0.000	0.000	0.002	0.345	0.687	0.845	0.935	0.992	1.032	1.102	1.154	1.180	1.205	1.218
2.25	0.000	0.000	0.000	0.001	0.324	0.660	0.816	0.905	0.962	1.002	1.071	1.123	1.148	1.173	1.186
2.26	0.000	0.000	0.000	0.000	0.304	0.634	0.789	0.876	0.933	0.972	1.041	1.092	1.117	1.142	1.155
2.27	0.000	0.000	0.000	0.000	0.285	0.609	0.762	0.848	0.904	0.943	1.011	1.062	1.087	1.112	1.124
2.28	0.000	0.000	0.000	0.000	0.267	0.585	0.735	0.821	0.876	0.915	0.982	1.033	1.058	1.082	1.095
2.29	0.000	0.000	0.000	0.000	0.250	0.561	0.710	0.794	0.849	0.887	0.954	1.004	1.029	1.053	1.065

^aValues tabulated are read in percent.

Table B-5--Continued

Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method¹

Qu or QL	Sample Size														
	3	4	5	7	10	15	20	25	30	35	50	75	100	150	200
2.30	0.000	0.000	0.000	0.000	0.233	0.538	0.685	0.769	0.823	0.861	0.927	0.977	1.001	1.025	1.037
2.31	0.000	0.000	0.000	0.000	0.218	0.516	0.661	0.743	0.797	0.834	0.900	0.949	0.974	0.998	1.009
2.32	0.000	0.000	0.000	0.000	0.203	0.495	0.637	0.719	0.772	0.809	0.874	0.923	0.947	0.971	0.982
2.33	0.000	0.000	0.000	0.000	0.189	0.474	0.614	0.695	0.748	0.784	0.848	0.897	0.921	0.944	0.956
2.34	0.000	0.000	0.000	0.000	0.175	0.454	0.592	0.672	0.724	0.760	0.824	0.872	0.895	0.919	0.930
2.35	0.000	0.000	0.000	0.000	0.163	0.435	0.571	0.650	0.701	0.736	0.799	0.847	0.870	0.893	0.905
2.36	0.000	0.000	0.000	0.000	0.151	0.416	0.550	0.628	0.678	0.714	0.776	0.823	0.846	0.869	0.880
2.37	0.000	0.000	0.000	0.000	0.139	0.398	0.530	0.606	0.656	0.691	0.753	0.799	0.822	0.845	0.856
2.38	0.000	0.000	0.000	0.000	0.128	0.381	0.510	0.586	0.635	0.670	0.730	0.777	0.799	0.822	0.833
2.39	0.000	0.000	0.000	0.000	0.118	0.364	0.491	0.566	0.614	0.648	0.709	0.754	0.777	0.799	0.810
2.40	0.000	0.000	0.000	0.000	0.109	0.348	0.473	0.546	0.594	0.628	0.687	0.732	0.755	0.777	0.787
2.41	0.000	0.000	0.000	0.000	0.100	0.332	0.455	0.527	0.575	0.608	0.667	0.711	0.733	0.755	0.766
2.42	0.000	0.000	0.000	0.000	0.091	0.317	0.437	0.509	0.555	0.588	0.646	0.691	0.712	0.734	0.744
2.43	0.000	0.000	0.000	0.000	0.083	0.302	0.421	0.491	0.537	0.569	0.627	0.670	0.692	0.713	0.724
2.44	0.000	0.000	0.000	0.000	0.076	0.288	0.404	0.474	0.519	0.551	0.608	0.651	0.672	0.693	0.703
2.45	0.000	0.000	0.000	0.000	0.069	0.275	0.389	0.457	0.501	0.533	0.589	0.632	0.653	0.673	0.684
2.46	0.000	0.000	0.000	0.000	0.063	0.262	0.373	0.440	0.484	0.516	0.571	0.613	0.634	0.654	0.664
2.47	0.000	0.000	0.000	0.000	0.057	0.249	0.359	0.425	0.468	0.499	0.553	0.595	0.615	0.636	0.646
2.48	0.000	0.000	0.000	0.000	0.051	0.237	0.345	0.409	0.452	0.482	0.536	0.577	0.597	0.617	0.627
2.49	0.000	0.000	0.000	0.000	0.046	0.226	0.331	0.394	0.436	0.466	0.519	0.560	0.580	0.600	0.609
2.50	0.000	0.000	0.000	0.000	0.041	0.214	0.317	0.380	0.421	0.451	0.503	0.543	0.563	0.582	0.592
2.51	0.000	0.000	0.000	0.000	0.037	0.204	0.305	0.366'	0.407	0.436	0.487	0.527	0.546	0.565	0.575
2.52	0.000	0.000	0.000	0.000	0.033	0.193	0.292	0.352	0.392	0.421	0.472	0.511	0.530	0.549	0.559
2.53	0.000	0.000	0.000	0.000	0.029	0.184	0.280	0.339	0.379	0.407	0.457	0.495	0.514	0.533	0.542
2.54	0.000	0.000	0.000	0.000	0.026	0.174	0.268	0.326	0.365	0.393	0.442	0.480	0.499	0.517	0.527
2.55	0.000	0.000	0.000	0.000	0.023	0.165	0.257	0.314	0.352	0.379	0.428	0.465	0.484	0.502	0.511
2.56	0.000	0.000	0.000	0.000	0.020	0.156	0.246	0.302	0.340	0.366	0.414	0.451	0.469	0.487	0.496
2.57	0.000	0.000	0.000	0.000	0.017	0.148	0.236	0.291	0.327	0.354	0.401	0.437	0.455	0.473	0.482
2.58	0.000	0.000	0.000	0.000	0.Q15	0.140	0.226	0.279	0.316	0.341	0.388	0.424	0.441	0.459	0.468
2.59	0.000	0.000	0.000	0.000	0.013	0.133	0.216	0.269	0.304	0.330	0.375	0.410	0.428	0.445	0.454
2.60	0.000	0.000	0.000	0.000	0.011	0.125	0.207	0.258	0.293	0.318	0.363	0.398	0.415	0.432	0.441
2.61	0.000	0.000	0.000	0.000	0.009	0.118	0.198	0.248	0.282	0.307	0.351	0.385	0.402	0.419	0.428
2.62	0.000	0.000	0.000	0.000	0.008	0.112	0.189	0.238	0.272	0.296	0.339	0.373	0.390	0.406	0.451
2.63	0.000	0.000	0.000	0.000	0.007	0.105	0.181	0.229	0.262	0.285	0.328	0.361	0.378	0.394	0.402
2.64	0.000	0.000	0.000	0.000	0.006	0.099	0.172	0.220	0.252	0.275	0.317	0.350	0.366	0.382	0.390
2.65	0.000	0.000	0.000	0.000	0.005	0.094	0.165	0.211	0.242	0.265	0.307	0.339	0.355	0.371	0.379
2.66	0.000	0.000	0.000	0.000	0.004	0.088	0.157	0.202	0.233	0.256	0.296	0.328	0.344	0.359	0.367
2.67	0.000	0.000	0.000	0.000	0.003	0.083	0.150	0.194	0.224	0.246	0.286	0.317	0.333	0.348	0.356
2.68	0.000	0.000	0.000	0.000	0.002	0.078	0.143	0.186	0.216	0.237	0.277	0.307	0.322	0.338	0.345
2.69	0.000	0.000	0.000	0.000	0.002	0.073	0.136	0.179	0.208	0.229	0.267	0.297	0.312	0.327	0.335

¹Values tabulated are read in percent.

*Table B-5-Continued*Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method¹

Qu or QL	Sample Size														
	3	4	5	7	10	IS	20	25	30	35	50	75	100	150	200
2.70	0.000	0.000	0.000	0.000	0.001	0.069	0.130	0.171	0.200	0.220	0.258	0.288	0.302	0.317	0.325
2.71	0.000	0.000	0.000	0.000	0.001	0.064	0.124	0.164	0.192	0.212	0.249	0.278	0.293	0.307	0.315
2.72	0.000	0.000	0.000	0.000	0.001	0.060	0.118	0.157	0.184	0.204	0.241	0.269	0.283	0.298	0.305
2.73	0.000	0.000	0.000	0.000	0.001	0.057	0.112	0.151	0.177	0.197	0.232	0.260	0.274	0.288	0.296
2.74	0.000	0.000	0.000	0.000	0.000	0.053	0.107	0.144	0.170	0.189	0.224	0.252	0.266	0.279	0.286
2.75	0.000	0.000	0.000	0.000	0.000	0.049	0.102	0.138	0.163	0.182	0.216	0.243	0.257	0.271	0.277
2.76	0.000	0.000	0.000	0.000	0.000	0.046	0.097	0.132	0.157	0.175	0.209	0.235	0.249	0.262	0.269
2.77	0.000	0.000	0.000	0.000	0.000	0.043	0.092	0.126	0.151	0.168	0.201	0.227	0.241	0.254	0.260
2.78	0.000	0.000	0.000	0.000	0.000	0.040	0.087	0.121	0.145	0.162	0.194	0.220	0.223	0.246	0.252
2.79	0.000	0.000	0.000	0.000	0.000	0.037	0.083	0.115	0.139	0.156	0.187	0.212	0.225	0.238	0.244
2.80	0.000	0.000	0.000	0.000	0.000	0.035	0.079	0.110	0.133	0.150	0.181	0.205	0.218	0.230	0.237
2.81	0.000	0.000	0.000	0.000	0.000	0.032	0.075	0.105	0.128	0.144	0.174	0.198	0.211	0.223	0.229
2.82	0.000	0.000	0.000	0.000	0.000	0.030	0.071	0.101	0.122	0.138	0.168	0.192	0.204	0.216	0.222
2.83	0.000	0.000	0.000	0.000	0.000	0.028	0.067	0.096	0.117	0.133	0.162	0.185	0.197	0.209	0.215
2.84	0.000	0.000	0.000	0.000	0.000	0.026	0.064	0.092	0.112	0.128	0.156	0.179	0.190	0.202	0.208
2.85	0.000	0.000	0.000	0.000	0.000	0.024	0.060	0.088	0.108	0.122	0.150	0.173	0.184	0.195	0.201
2.86	0.000	0.000	0.000	0.000	0.000	0.022	0.057	0.084	0.103	0.118	0.145	0.167	0.178	0.189	0.195
2.87	0.000	0.000	0.000	0.000	0.000	0.020	0.054	0.080	0.099	0.113	0.139	0.161	0.172	0.183	0.188
2.88	0.000	0.000	0.000	0.000	0.000	0.019	0.051	0.076	0.094	0.108	0.134	0.155	0.166	0.177	0.182
2.89	0.000	0.000	0.000	0.000	0.000	0.017	0.048	0.073	0.090	0.104	0.129	0.150	0.160	0.171	0.176
2.90	0.000	0.000	0.000	0.000	0.000	0.016	0.046	0.069	0.087	0.100	0.125	0.145	0.155	0.165	0.171
2.91	0.000	0.000	0.000	0.000	0.000	0.015	0.043	0.066	0.083	0.096	0.120	0.140	0.150	0.160	0.165
2.92	0.000	0.000	0.000	0.000	0.000	0.013	0.041	0.063	0.079	0.092	0.115	0.135	0.145	0.155	0.160
2.93	0.000	0.000	0.000	0.000	0.000	0.012	0.038	0.060	0.076	0.088	0.111	0.130	0.140	0.149	0.154
2.94	0.000	0.000	0.000	0.000	0.000	0.011	0.036	0.057	0.072	0.084	0.107	0.125	0.135	0.144	0.149
2.95	0.000	0.000	0.000	0.000	0.000	0.010	0.034	0.054	0.069	0.081	0.103	0.121	0.130	0.140	0.144
2.96	0.000	0.000	0.000	0.000	0.000	0.009	0.032	0.051	0.066	0.077	0.099	0.117	0.126	0.135	0.140
2.97	0.000	0.000	0.000	0.000	0.000	0.009	0.030	0.049	0.063	0.074	0.095	0.112	0.121	0.130	0.135
2.98	0.000	0.000	0.000	0.000	0.000	0.008	0.028	0.046	0.060	0.071	0.091	0.108	0.117	0.126	0.130
2.99	0.000	0.000	0.000	0.000	0.000	0.007	0.027	0.044	0.057	0.068	0.088	0.104	0.113	0.122	0.126
3.00	0.000	0.000	0.000	0.000	0.000	0.006	0.025	0.042	0.055	0.065	0.084	0.101	0.109	0.118	0.122
3.01	0.000	0.000	0.000	0.000	0.000	0.006	0.024	0.040	0.052	0.062	0.081	0.097	0.105	0.113	0.118
3.02	0.000	0.000	0.000	0.000	0.000	0.005	0.022	0.038	0.050	0.059	0.078	0.093	0.101	0.110	0.114
3.03	0.000	0.000	0.000	0.000	0.000	0.005	0.021	0.036	0.048	0.057	0.075	0.090	0.098	0.106	0.110
3.04	0.000	0.000	0.000	0.000	0.000	0.004	0.019	0.034	0.045	0.054	0.072	0.087	0.094	0.102	0.106
3.05	0.000	0.000	0.000	0.000	0.000	0.004	0.018	0.032	0.043	0.052	0.069	0.083	0.091	0.099	0.103
3.06	0.000	0.000	0.000	0.000	0.000	0.003	0.017	0.030	0.041	0.050	0.066	0.080	0.088	0.095	0.099
3.07	0.000	0.000	0.000	0.000	0.000	0.003	0.016	0.029	0.039	0.047	0.064	0.077	0.085	0.092	0.096
3.08	0.000	0.000	0.000	0.000	0.000	0.003	0.015	0.027	0.037	0.045	0.061	0.074	0.081	0.089	0.092
3.09	0.000	0.000	0.000	0.000	0.000	0.002	0.014	0.026	0.036	0.043	0.059	0.072	0.079	0.086	0.089

¹Values tabulated are read in percent.

*Table B-5-Continued*Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method^d

Qu QL	Sample Size														
	3	4	5	7	10	15	20	25	30	35	50	75	100	150	200
3.10	0.000	0.000	0.000	0.000	0.000	0.002	0.013	0.024	0.034	0.041	0.056	0.069	0.076	0.083	0.086
3.11	0.000	0.000	0.000	0.000	0.000	0.002	0.012	0.023	0.032	0.039	0.054	0.066	0.073	0.080	0.083
3.12	0.000	0.000	0.000	0.000	0.000	0.002	0.011	0.022	0.031	0.038	0.052	0.064	0.070	0.077	0.080
3.13	0.000	0.000	0.000	0.000	0.000	0.002	0.011	0.021	0.029	0.036	0.050	0.061	0.068	0.074	0.077
3.14	0.000	0.000	0.000	0.000	0.000	0.001	0.010	0.019	0.028	0.034	0.048	0.059	0.065	0.071	0.075
3.15	0.000	0.000	0.000	0.000	0.000	0.001	0.009	O.D18	0.026	0.033	0.046	0.057	0.063	0.069	0.072
3.16	0.000	0.000	0.000	0.000	0.000	0.001	0.009	0.017	0.025	0.031	0.044	0.055	0.060	0.066	0.069
3.17	0.000	0.000	0.000	0.000	0.000	0.001	0.008	0.016	0.024	0.030	0.042	0.053	0.058	0.064	0.067
3.18	0.000	0.000	0.000	0.000	0.000	0.001	0.007	0.015	0.022	0.028	0.040	0.050	0.056	0.062	0.065
3.19	0.000	0.000	0.000	0.000	0.000	0.001	0.007	O.D15	0.021	0.027	0.038	0.049	0.054	0.059	0.062
3.20	0.000	0.000	0.000	0.000	0.000	0.001	0.006	0.014	0.020	0.026	0.037	0.047	0.052	0.057	0.060
3.21	0.000	0.000	0.000	0.000	0.000	0.000	0.006	0.013	0.019	0.024	0.035	0.045	0.050	0.055	0.058
3.22	0.000	0.000	0.000	0.000	0.000	0.000	0.005	0.012	O.Q\8	0.023	0.034	0.043	0.048	0.053	0.056
3.23	0.000	0.000	0.000	0.000	0.000	0.000	0.005	0.011	0.017	0.022	0.032	0.041	0.046	0.051	0.054
3.24	0.000	0.000	0.000	0.000	0.000	0.000	0.005	O.ot I	0.016	0.021	0.031	0.040	0.044	0.049	0.052
3.25	0.000	0.000	0.000	0.000	0.000	0.000	0.004	0.010	O.o15	0.020	0.030	0.038	0.043	0.048	0.050
3.26	0.000	0.000	0.000	0.000	0.000	0.000	0.004	0.009	O.Q\5	0.019	0.028	0.037	0.041	0.046	0.048
3.27	0.000	0.000	0.000	0.000	0.000	0.000	0.004	0.009	0.014	O.QJ8	0.027	0.035	0.040	0.044	0.046
3.28	0.000	0.000	0.000	0.000	0.000	0.000	0.003	0.008	0.013	0.017	0.026	0.034	0.038	0.042	0.045
3.29	0.000	0.000	0.000	0.000	0.000	0.000	.0003	0.008	0.012	0.016	0.025	0.032	0.037	0.041	0.043
3.30	0.000	0.000	0.000	0.000	0.000	0.000	0.003	0.007	0.012	O.G15	0.024	0.031	0.035	0.039	0.042
3.31	0.000	0.000	0.000	0.000	0.000	0.000	0.003	0.007	O.QII	0.015	0.023	0.030	0.034	O.oJ8	0.040
3.32	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.006	0.010	0.014	0.022	0.029	0.032	0.036	0.038
3.33	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.006	0.010	0.013	0.021	0.027	0.031	O.o35	0.037
3.34	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.006	0.009	0.013	0.020	0.026	0.030	0.034	0.036
3.35	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.005	0.009	0.012	0.019	O.ozs	0.029	0.032	0.034
3.36	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.005	0.008	0.011	0.018	0.024	0.028	0.031	0.033
3.37	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.005	0.008	O.DII	0.017	0.023	0.026	0.030	0.032
3.38	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.004	0.007	0.010	0.016	0.022	O.o25	0.029	0.031
3.39	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.004	0.007	0.010	0.016	0.021	O.Q28	0.024	0.029
3.40	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.004	0.007	0.009	O.D15	0.020	0.023	0.027	0.028
3.41	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.003	0.006	0.009	0.014	0.020	0.022	0.026	0.027
3.42	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.003	0.006	0.008	0.014	0.019	0.022	0.025	0.026
3.43	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.003	0.005	0.008	0.013	O.D18	0.021	0.024	0.025
3.44	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.003	0.005	0.007	0.012	0.017	0.020	0.023	0.024
3.45	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.003	0.005	0.007	0.012	0.016	0.019	0.022	0.023
3.46	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.005	0.007	0.011	0.016	0.018	0.021	0.022
3.47	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.004	0.006	O.Q\1	O.o5	0.018	0.020	0.022
3.48	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.004	0.006	0.010	0.014	0.017	0.019	0.021
3.49	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.004	0.005	0.010	0.014	0.016	0.019	0.020

•Values tabulated are read in percent.

*Table B-5-Continued*Table for Estimating the Lot Percent Non-Conforming Using Standard Deviation Method¹

Qu or QI	Sample Size														
	3	4	5	7	10	15	20	25	30	35	50	75	100	150	200
3.50	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.003	0.005	0.009	0.013	0.015	0.018	0.019
3.51	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.003	0.005	0.009	0.013	O.D15	0.017	0.018
3.52	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.003	0.005	0.008	0.012	0.014	0.016	O.QI8
3.53	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.003	0.004	0.008	0.011	0.014	0.01	0.011
3.54	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.003	0.004	0.008	0.011	0.013	6	0.016
3.55	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.003	0.004	0.007	0.011	0.012	O.J5	0.016
3.56	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.004	0.007	0.010	0.012	O.D15	0.015
3.57	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.006	0.010	0.011	0.014	0.014
3.58	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.006	0.009	0.011	0.01	0.014
3.59	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.006	0.009	0.010	0.01	0.013
3.60	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.006	0.008	0.010	0.012	0.013
3.61	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.005	0.008	0.010	O.DII	0.012
3.62	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.005	0.008	0.009	0.011	0.012
3.63	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.005	0.007	0.009	0.010	0.011
3.64	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.004	0.007	0.008	0.010	O.OII
3.65	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.004	0.007	0.008	0.010	0.010
3.66	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.004	0.006	0.008	0.009	0.010
3.67	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.004	0.006	0.007	0.009	0.010
3.68	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.002	0.004	0.006	0.007	0.008	0.009
3.69	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.005	0.007	0.008	0.009
3.70	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.005	0.006	0.008	0.008
3.71	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.003	0.005	0.006	0.007	0.008
3.72	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.003	0.005	0.006	0.007	0.008
3.73	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.003	0.005	0.006	0.007	0.007
3.74	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.003	0.004	0.005	0.006	0.007
3.75	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.004	0.005	0.006	0.007
3.76	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.004	0.005	0.006	0.007
3.77	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.004	0.005	0.006	0.006
3.78	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.004	0.004	0.005	0.006	0.006
3.79	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.004	0.005	0.006	
3.80	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.004	0.005	0.006	
3.81	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.004	0.005	0.005	
3.82	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.004	0.005	0.005	
3.83	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.004	0.004	0.004	
3.84	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.003	0.003	0.004	0.005	
3.85	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.002	0.003	0.004	
3.86	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.003	0.004	
3.87	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.003	0.004	
3.88	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.001	0.002	0.003	0.004	
3.89	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.003	0.004	
3.90	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.001	0.002	0.003	0.003	0.004	

¹Values tabulated are read in percent.